

INDEX NO.	DESCRIPTION	PART NO.	REQ'D. NO.
1	T-Handle End Cap	215403	2
2	Handle	255626	1
3	Pin	215145	2
4	Retaining Ring	215254	2
5	Cylinder	215109	1
6	Cylinder Assembly Complete	215102	1
7	Retaining Ring	215142	1
*8	Ram U-Cup	215112	1
9	Ram	215111	1
10	Pin	215141	1
11	Cylinder Bearing	215607	1
12	Retaining Ring	215125	2
13	Oil Brake	215527	1
14	Spring	215526	1
15	Saddle Cover	215152	1
16	Elevator Arm Assembly	215516	1
17	Lifting Saddle	215151	1
18	Retaining Ring	255135	2
19	Pin	255636	1
20	Torsion Spring	255133	1
21	Handle Base Screw	255122	1
22	Handle Base	255123	1
23	Cotter Pin	255132	1
24	Cotter Pin	215206	1
25	Nut	255128	2
26	Release Arm	255131	1
27	Release Hub	255130	1
28	Release Lever	255127	1
29	Pump Pedal	255627	1
30	Torsion Spring	255629	1
31	Caster Assembly	255177	2
32	Chassis	215515	1
33	Spring	215119	2
34	Elevator Arm Shaft	215144	1
35	Retaining Ring	215143	2
36	Front Wheel	215517	2
37	Retaining Ring	215135	2
38	Release Guide Bushing	255112	1
*39	Release Oil Seal	255111	1
40	Tube Assembly	215114	1
41	Cover Screw (Intake)	255017	1
*42	Copper Gasket	255018	2
*43	Checkball, .312 Diameter	9005	2
44	Cover Screw (Discharge)	255020	1
45	Overload Spring	255525	1
*46	Checkball, .250 Diameter	9004	1
*47	O-Ring	255523	1
48	Cover Screw (Overload)	255524	1
*49	Reservoir Fill Plug	255015	1
50	Oil Block	215964	1
51	Mounting Bolt	255166	2
52	Nut	255169	2
*53	Pump Piston U-Cup	255136	1
*54	Brass Retainer Washer	255137	1
55	Retaining Ring	255138	1
56	Pump Piston	255139	1
57	Connecting Rod	255141	2
58	Hyd. Block Assy. Complete	215957	1
59	Rivet Pin	255121	2
60	Retaining Ring	255120	4
*61	O-Ring	255142	2
62	Pump Bearing (Brass)	255143	1
*63	Checkball, .156 Diameter	9021	1
64	Spring Guide	255116	1
65	Release Spring	255115	1
66	Release Shaft	255114	1
*67	Gasket	255113	1

* Designates those parts found in repair kit part # 215600