



\*50 designates those parts included  
in repair kit 220090

**REPLACEMENT  
PARTS**

**MODEL NO.  
72090**

**CAPACITY  
20 TON**

**DESCRIPTION  
AIR/HYDRAULIC FLOOR JACK**



INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Extension screw assembly	621005	1
2	Snap ring	621011	1
*3	O-ring, ram wiper	621012	1
4	Upper bearing	621026	2
5	Ram	621024	1
6	Limit pin	621016	1
7	Ram bearing (A)	621017	1
*8	Backup ring	621018	1
*9	O-ring, ram	621019	1
10	Ram bearing (B)	621021	1
11	Valve pin	621022	1
12	Checkball, 1/4" diameter	9004	1
13	Spring	4007	1
14	Retainer	2005	1
15	Spring hanger	220069	1
16	4" ram extension	220057	2
17	Base assembly	220060	1
18	Washer	220064	4
19	Wheel	220062	2
20	Cotter pin	220063	2
21	Flat head screw	3173	3
22	Split medium lockwasher	2007	6
23	3/8" - 16 hex nut	1073	3
*24	Checkball, 7/32" diameter	9001	1
*25	O-ring	12001	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
26	Release valve	602058	1
27	Slip lock tube receiver	220083	2
*28	Check ball, 5/16" diameter	9005	1
29	3/8" - 16 x 2 hex head bolt	11027	1
30	Black tube	220084	1
31	3/8" - 16 jam nut	1079	3
32	Universal joint w/set screw	220055	1
33	Slip collar w/set screw	220050	1
34	Release knob	602064	1
35	1/8 NPT female elbow	220074	1
36	One-way valve	220079	1
37	1/8 NPT female "T"	220076	1
38	Air pump	220100	1
39	1/4 to 1/8 NPT male reducer	220077	1
40	Hose assembly	220070	1
41	Air motor adapter	220066	1
42	Air valve holder	220068	1
43	Air valve	220067	1
44	In-line filter	220072	1
45	Air nipple disconnect	220078	1
46	Handle assembly	220045	1
47	Hand grip	220046	1
48	Release shaft	220051	1
49	Retraction spring	220071	2
50	Repair kit	220090	1