



REPLACEMENT PARTS

MODEL NO.
72475

CAPACITY
3/4 TON

DESCRIPTION
AIR/HYDRAULIC TELESCOPIC TRANSMISSION JACK



INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO	INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO	INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO	INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
°1	Wiper Ring	282801	1	46	Rubber Grip	282833	2	91	Retaining Ring	282511	1	136	Washer	282841	4
°2	Seal	282802	1	47	Handle Assembly	282835	1	92	Allen Socket Cap Screw	282512	8	137	Containing Angle	282842	4
3	Secondary Cylinder Nut	282803	1	48	Screws	282834	4	93	Filter	282513	1	138	Washer	282843	4
4	Checkball	282404	1	49	Rubber Shield	282458	1	94	Disc	282514	1	139	Retaining Ring	282844	2
5	Set Screw	282406	1	*50	O-ring	282836	1	95	Air Pump Body	282503	1	140	Knob	282846	4
°6	O-ring	282804	1	51	Hydraulic Base	282837	1	*96	O-ring	282517	1	141	Nut	282847	4
°7	Seal	282806	1	52	Screw	282462	4	*97	Backup Ring	282518	1	142	Retaining Ring	282848	1
°8	Seal	282807	1	53	Flat Washer	282463	4	*98	O-ring	282519	1	143	Tilt Screw	282849	1
9	Primary Cylinder Nut	282808	1	54	Lock Washer	282464	4	99	Bottom Bolt Fitting	282521	1	144	Trunion	282851	1
10	Air Valve	282412	1	55	Hex Head Screw	282466	4	*100	U-cup Seal	282522	1	145	Nut	282852	1
11	Pin	282413	1	56	Washer	282467	8	101	Spring Guide	282523	1	146	Trunion	282853	1
°12	O-ring	282414	2	57	Allen Socket Cap Screw	282468	8	102	Screw	282524	4	147	Set Screw	282854	2
13	Air Valve Body	282416	1	58	Leg Assembly	282830	4	103	Air Pump Spring	282526	1	148	Retaining Ring	282856	2
°14	Seal	282417	4	59	Elbow Fitting	282557	2	104	Hydraulic Piston	282527	1	149	Universal Saddle Assembly	282855	1
15	Pipe Elbow	282418	1	60	Hose Assembly	282840	1	105	Spring/Piston Retainer	282528	1	150	Saddle Tilt Pin	282857	1
16	Vent Body	282419	1	61	Fitting	282473	1	*106	O-ring	282529	2	151	Collar	282858	2
17	Air Filter	282421	1	62	Retaining Ring	282474	2	*107	Quad Ring	282531	2	152	Flat Washer	2072	16
°18	Seal	282422	1	63	Pivot Pin	282476	1	108	Front Air Piston Half	282532	1	153	Locknut	1054	16
19	Valve Holder	282423	1	64	Allen Socket Cap Screw	282477	2	*109	O-ring	282533	1	154	Bolt	11007	16
20	Valve	282424	1	65	Washer	282478	2	110	Shuttle Valve	282534	1	155	Cotter Pin	282859	2
21	Valve Seat	282426	1	66	Pressure Plate	282479	1	111	Rear Air Piston Half	282536	1	156	Castle Nut	282861	2
22	Washer	282427	1	67	Sponge Filter	282481	1	*112	Rubber Stopper	282537	1	157	Retaining Ring	282862	2
23	End Fitting	282428	1	68	Allen Socket Cap Screw	282482	2	113	Screw	282538	3	158	Saddle Tilt Pin	282863	1
24	Reservoir Fill Plug	282429	1	69	Pump Manifold	282483	1	114	Air Cylinder	282539	1	159	Pivot Base Assembly	282860	1
25	Allen Socket Button Screw	282431	4	*70	O-ring	282484	1	*115	O-ring	282541	1	160	Retaining Ring	282864	6
°26	O-ring	282432	2	71	Release Valve	282486	1	116	Air Cylinder End Cap	282542	1	161	Anchor Trunion	282866	2
°27	Seal	282809	1	*72	O-ring	282487	1	*117	O-ring	282838	2	162	Threaded Trunion	282867	1
°28	O-ring	282811	1	73	Spring	282488	1	118	Allen Socket Cap Screw	282544	6	163	Bearing Assembly	282865	4
29	Ram, Secondary	282812	1	74	Valve Guide	282489	1	119	Elbow Fitting	282546	1	164	Saddle Base Assembly	282870	1
30	Ram Bearing, Secondary	282813	1	*75	Backup Ring	282491	2	120	Filter Screen	282547	1	165	Bolt	282868	1
31	Pin	282814	1	*76	O-ring	282492	2	121	Optional Male Air Disconnect	282548	1	166	Tilt Screw	282869	1
32	Primary Ram	282816	1	77	Pin	282493	1	122	Pipe & Fitting Assembly	282410	1	167	Expansion Pin	282871	2
33	Pin	282817	1	78	Valve Stem	282494	1	*123	O-ring	282549	2	168	Tilt Handle	282872	2
34	Ram Bearing, Primary	282818	1	*79	Checkball	282496	1	124	Pump Stem Assembly	282845	1		°Cylinder/Ram Seal Kit	282805	1
°35	Backup Ring	282819	1	80	Spring	282497	1	*125	O-ring	282552	1		* Pump Kit	282885	1
°36	O-ring Seal	282821	1	*81	Backup Ring	282498	1	126	Spring	282553	1				
37	Ring	282822	1	82	Housing	282499	1	127	Allen Socket Set Screw	282554	1				
38	Fitting	282823	1	83	Spring	282501	1	128	Pump Support Bracket	282556	1				
°39	Checkball	282824	1	*84	Checkball	282502	2	129	Spring	282899	1				
40	Valve Pin	282826	1	85	Pump Pedal	282472	1	130	Locking Caster Assembly	282820	2				
41	Protrusion	282827	1	86	Allen Socket Cap Screw	282504	4	131	Complete Pump Assembly	282825	1				
42	Sleeve	282828	1	87	Allen Socket Cap Screw	282506	1	132	Caster Assembly	282815	2				
43	Primary Cylinder	282829	1	*88	O-ring	282507	2	133	Complete Saddle Assembly	282850	1				
44	Pump Block	282831	1	89	Housing	282508	1	134	Flat Head Bolt	282839	4				
45	Reservoir Tube	282832	1	90	Screen	282509	1	135	Bushing	282873	4				

° The dot designates those parts included in the Cylinder/Ram Seal Kit Part No. 282805

* The asterisk designates those parts included in the Pump Seal Kit Part No. 282885