


norgo

DESCRIPTION
AIR / HYDRAULIC FLOOR JACK

CAPACITY
5 TON

MODEL NO.
71550 B&C

REPLACEMENT
PARTS



INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Handle Grip	251113	2
2	Handle	255746	1
3	Cover Screw	255639	4
4	Cover	255188	1
5	Cylinder B,C	255811	1
6	Cylinder Assy. Complete B,C	255815	1
7	Retaining Ring B,C	255812	1
*8	Ram Seal B,C	255813	1
9	Ram B,C	255814	1
*10	O-Ring B,C	255816	1
11	Cylinder Nut B,C	255817	1
12	Washer B,C	255837	1
13	Nipple B,C	255838	1
*14	O-Ring	255496	1
15	Screw	255214	1
16	Elevator Arm Assy.	255176	1
17	Lifting Saddle	255163	1
18	Retaining Ring	255135	2
19	Bolt B,C	255818	1
20	Extension Spring	255749	1
21	Handle Base Screw	255122	1
22	Handle Base	255123	1
23	Cotter Pin	255132	1
24	Cotter Pin	255206	1
25	Nut	255128	2
26	Release Arm	255131	1
27	Release Hub	255130	1
28	Release Lever	255127	1
29	Pump Pedal B,C	255835	1
30	Air Pump Assy. Complete B,C	255820	1
31	Caster Assembly	255177	2
32	Chassis Assembly B.C	255822	1
33	Spring	255162	1
34	Elevator Arm Shaft	255186	1
35	Retaining Ring	255175	2
36	Front Wheel	255164	2
37	Fiat Washer	255168	2
38	Elbow Fitting B,C	255839	1
39	Filter Housing B,C	255841	1
40	Fill Screw Gasket B,C	255823	1
41	Cover Screw (intake)	255017	1
*42	Copper Gasket	255018	2
*43	Checkball, .312 diameter	9005	2
44	Cover Screw (discharge)	255020	1
45	Overload Spring	255525	1
*46	Checkball, .250 diameter	9004	1
*47	O-Ring	255523	1
48	Cover Screw (overload)	255524	1
49	Reservoir Fill Screw B.C	255821	1
50	Oil Block Assembly B.C	255825	1
51	Mounting Bolt	255166	2
52	Mounting Nut	255167	2
*53	Pump Piston U-Cup	255136	1
*54	Brass Retainer Washer	255137	1
55	Retaining Ring	255138	1
56	Pump Piston	255139	1
57	Connecting Rod	255141	2
58	Hydraulic Block Assy. Complete B,C	255830	1
59	Rivet Pins	255144	2
60	Retaining Ring	255120	4
*61	O-Ring	255142	2
62	Pump Bearing (Brass)	255143	1
*63	Checkball, .156 diameter	9021	1
64	Spring Guide	255116	1
65	Release Spring	255115	1
66	Release Shaft	255114	1
*67	Gasket	255113	1
68	Release Guide Bushing	255112	1
*69	Release Oil Seal	255111	1
70	Filter B,C	255842	1
71	Copper Washer B,C	255843	1
72	Connector B.C	255826	1
73	Air Valve	255759	1
74	Male Air Coupler	255761	1

* Parts included in Hydraulic Repair Kit 255910

INDEX NO.	DESCRIPTION	PART NO.	QTY.
75	Screw B,C	255827	4
76	Washer	255763	4
77	Silencer Cover	255764	1
78	Silencer B,C	255828	1
*79	Rubber Gasket	255767	1
80	Screw	255829	1
81	Air Valve Block B,C	255831	1
82	Gasket A,B,C	255832	1
*83	Glide Ring with O-Ring A,B,C	255833	1
84	Air Piston B,C	255834	1
*85	O-Ring A,B,C	255836	1
86	Nipple B,C	255846	1
87	Copper Washer B,C	255847	1
88	Hydraulic Piston B,C	255848	1
89	Washer A,B,C	255849	1
90	Nut A,B,C	255851	1
91	Hose A,B,C	255852	1
92	Air Connector A,B,C	255853	1
93	Bronze Bearing A,B,C	255854	1
*94	Seal A,B,C	255856	1
95	Spring A,B,C	255857	1
96	Air Cylinder B,C	255858	1
97	Pump Piston Housing B,C	255859	1
*98	Copper Ring	255861	2
99	Nylon Sleeve	255792	1
100	Screw	255793	1
101	Washer	255794	1
102	Nut	255796	1
*103	Copper Ring	255797	1
*104	O-Ring	255798	1
105	Guide	255799	1
106	Support Shaft	255801	1
*107	O-Ring	255802	1
108	Valve Housing	255803	1
109	Fitting B,C	255862	1
110	Nipple B,C	255863	1
*111	Copper Ring B.C	255864	3
112	Spring	255865	2
113	Checkball	255867	2
114	Nipple B,C	255868	1
115	Fitting B,C	255869	2
116	Nut B,C	255871	1
117	Bolt	255872	2
118	Hydraulic Block B.C	255873	1
119	Cap A,B,C	255874	1
120	Bolt A,B,C	255876	2
121	Cover B,C	255877	1
122	Air Connector B.C	255878	1
*123	O-Ring A,B,C	255879	3
124	Spring A,B,C	255881	1
125	Spring Lock A,B,C	255882	1
126	Sleeve A,B,C	255883	1
127	Pressure Valve B.C	255884	1
128	Piston Guide A,B,C	255886	1
129	Pipe A,B,C	255887	1
130	Pump Piston A,B,C	255888	1
131	Sleeve A,B,C	255889	1
132	Cover A,B,C	255891	1
133	Screw A,B,C	255892	2
136	Oil Valve A,B,C	255893	1
137	Handle Sleeve	255804	1
138	"Y" Air Fitting B.C	255894	1
139	Air Line C	255896	1
140	Screw	255897	2
141	Pipe	255898	1
142	Air Pump Cover B.C	255899	1
143	Protector C	255901	1
144	Retaining Ring	255135	2
145	Shaft	255636	1
146	Rubber Block B,C	255902	1
147	Pressure Tube	255903	1
148	Pressure Tube	255904	1
149	Ball	255906	1
150	Screw	255907	1

* Parts included in Air Pump Repair Kit 255915