



INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
1	Release Valve	603182	1
*2	O-Ring, M2.4 x 6.3	603183	1
3	Lever Linkage Assembly	605187	1
*4	Oil Filter Plug	603192	1
*5	Handle Assembly	603161	1
*6	Backup Ring	605162	1
*7	O-Ring, M3 x 12	605163	1
8	Pump Plunger	605164	1
9	8mm Retaining Ring	605166	2
10	Pin Link	605168	2
11	Extension Screw Assembly	608145	1
*12	Backup Ring	608136	1
*13	O-Ring, M5 x 27	608137	1
14	Ram Bearing (B)	608138	1
15	Ram Bearing (A)	608139	1
16	Snap Ring	608141	1
17	Stuffing Ring	608142	1
*18	O-Ring, M4 x 35	608143	1
19	Upper Bearing	608144	1
20	Ram	608146	1
21	Star Retainer		1
22	Plug		1
23	Adjustment Screw		1
24	spring		1
25	Cap for O.L. Spring		1
26	Check Ball		1

\* Items in Repair Kit 608200

REPLACEMENT  
PARTS

MODEL NO.  
76508B

CAPACITY  
8 TON

DESCRIPTION  
BOTTLE JACK

04-02-26

**norco**