



REPLACEMENT  
PARTS

MODEL NO.  
78200A

CAPACITY  
2000 LBS.

DESCRIPTION  
ENGINE STAND

**norco**

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
1	Gear Housing, Upright for 78200A	45100372	1
2	Upright 78200A	45100373	1
3	Main Base Tube for 78200A	45100374	1
4	Extension for 78200A	45100375	1
5	Main Base Crossmember for 78200A	45100376	1
6	Mounting Plate for 78200A	45100377	2
7	Adapter Bracket for 78200A	45100378	8
8	Adapter Arm for 78200A	45100379	8
9	Knuckle, Adapter Arm for 78200A	45100380	8
10	Exterior Washer for 78200A	45100381	1
11	Worm Gear for 78200A	45100382	1
12	Interior Washer for 78200A	45100383	1
13	Worm for 78200A	45100384	1
14	Adjusting Nut for 78200A	45100385	1
15	Bearing Container for 78200A	45100386	1
16	Handle Lever for 78200A	45100387	1
17	Handle for 78200A	45100388	1
18	Drive Shaft for 78200A	45100389	1
19	Rotating Shaft for 78200A	45100390	1
20	Wheel for 78200AA	45100391	2
21	Swivel Caster for 78200A	45100392	1
22	Swivel Caster with Lock for 78200A	45100393	1
23	Exterior Self Lubricating Flange Bearing for 78200A	45100394	2
24	Interior Self Lubricating Flange Bearing for 78200A	45100395	2
25	Bushing for 78200A	45100396	2
27	Washer for 78200A	45100397	8
28	Allen Screw for Worm Gear for 78200A	45100398	1
29	Key for 78200A	45100399	1
30	Gear Housing, Upright Hex Bolt for 78200A	45100400	5

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
31	Ball Bearing, Small for 78200A	45100401	1
32	Upright hex Bolt for 78200A	45100402	2
33	Lock Pin for 78200A	45100403	1
34	Hex Screw for Casters for 78200A	45100404	8
35	Axle Bolt	45100405	2
36	Mounting Plate Hex Screw for 78200A	45100406	4
37	Handle Lever Nut for 78200A	45100407	1
38	Cover Plate for 78200A	45100408	1
39	Allen Screw for Cover Plate for 78200A	45100409	4
40	Round head Bolt for 78200A	45100410	2
41	Allen Screw for Handle for 78200A	45100411	4
42	Lockwasher for Handle for 78200A	45100412	4
43	Friction Pad Holder for 78200A	45100413	1
44	Adjusting Bolt for 78200A	45100414	1
45	Spring for 78200A	45100415	1
46	Set Screw for 78200A	45100416	1
47	Flat Washer Cover Plate for 78200A	45100417	4
48	Lockwasher for Gearhouse for 78200A	45100418	4
49	Flat Washer for Caster for 78200A	45100419	8
50	Flat Washer for Gearhousing Upright for 78200A	45100420	9
51	Nut Gear Box for 78200A	45100421	2
52	Nut for Mounting Plate for 78200A	45100422	8
53	Nyloc Nut for Gear Housing for 78200A	45100423	9
54	Nyloc Nut for Caster for 78200A	45100424	8
55	Bracket for 78200A	45100425	8
56	Adjustment Knob Assembly for 78200A	45100371	1
57	Flat Washer Knob for 78200A	45100426	1
60	Hex Bolt for L-Bracket for 78200A	45100427	16